


MINT LED

LED SCEPTRE BLOOM



Operation Instructions

Operation Instructions

Introduction

Thank you for purchasing the MINT LED BLOOM Sceptre! Please review the following instructions to ensure you receive the best performance possible. Every ruler should have a sceptre, and when you rule over your plants it only fits that you should have one too! We proudly introduce to you the MINT LED 4' LED Bloom Sceptre. Drawing just 59 Watts and made of lightweight aluminum, this fixture gives you the ability to deliver light where you see fit! Use this light for flowering in a tent, all out flowering, or even as a supplemental light in your flowing room. With a great bloom spectrum, the 28 diodes in this light combined with a unique high transmittance lens guarantee outstanding PPFD output and a proper light coverage. The fixture's UV and IR will help to promote resin growth and an all-around higher quality flower. Make your room MINT condition with MINT LED!

1. Contents

- A. MINT LED Sceptre (BLOOM) Fixture (1)
- B. Power Supply (1)
- C. Power Cord (1)
- D. Hanging Hardware (2)
- E. Brass Anchors (2)
- F. Hanging Brackets (2)

3. Installation

1. Switch the main power off.
2. Install the fixture into a fixed and secure position using the provided hardware.
3. Hang the fixture only by its designated mounting points with the provided hardware.
4. Install the provided power cables from the fixture to the provided power supply and lastly the power supply into a powered outlet. (Inspect all powered wiring for any damage prior to installation.)
4. Switch the main power on when installation is complete to begin programming and using your fixture.

5. Warnings

MINT LED fixtures are designed for indoor use only! Do not place the fixture/s, associated electronics, and/or powered accessories near foggers, misters, or any devices that produce significant moisture. Do not place equipment in ambient rooms with a humidity rating greater than or equal to 80%. Use MINT LED fixtures with properly grounded powered outlets only. Ensure that all MINT LED equipment, including the provided contents, is undamaged and in proper working order prior to use. MINT LED fixtures should be installed in a fixed and well secured position only. Ensure the lamps and fixture body receives adequate ventilation for heat and that the heat vents are not obstructed. Do not stare directly into the LED diodes when the unit is powered on without proper eye protection.



DL Wholesale Inc.

7041 Las Positas Rd Ste A

Livermore CA 94551

www.dlwholesale.com / 510.550.0018