



## Operation Instructions

Thank you for purchasing the GROW1 Digital Nutrient Scale!  
Please Read all operating instructions carefully before use to  
ensure you receive the best performance possible.

### Operation

1. For proper readings, place the scale on a flat surface.
2. To turn the scale on, press the ON/OFF button.
3. Wait until the screen displays 0.0.
4. Place object/s or nutrients on the scale's weighing surface.
5. Press the MODE button to switch between measuring units.  
(Available measuring units: grams (g), ounces (oz),  
troy ounces (ozt), pennyweight (dwt))
6. To use the Tare function, press the ON/OFF button once.
7. To turn the scale off, press and hold the ON/OFF button for 5  
seconds.

### Calibration

1. Turn on the scale using the ON/OFF button.
2. Press and hold the MODE button until the screen displays  
CAL, then release the MODE button.
3. Press the MODE button again and the screen will display CAL  
followed by the required calibration weight value.  
(ex. 1000.0g)
4. Place the required calibration weight on the center of the  
scale's weighing surface. This must be an object that has a  
confirmed weight that is the same as the calibration value.
5. The screen will display PASS and then return to the default  
weighing mode.
6. Calibration is now complete.

### Warning

- Never overload the scale with more than the recommended  
maximum weight.
- Avoid exposure to extreme hot or cold temperatures and high  
humidity. For best results, use at a room temperature state.
- Give the scale sufficient warm-up time to receive proper  
readings. (30-60 seconds)
- Store/use the scale in a clean and stable environment void of  
dust, dirt, moisture, vibrations, and other disruptive electronics.
- Always handle the scale with extreme care and avoid  
dropping, shaking, or otherwise damaging the scale.
- Only operate the scale on a stable, flat, vibration free surface  
to receive the most accurate readings.